

ECOSTARTER

Single-component water-based acrylic primer for wooden floors



Description

ECOSTARTER is a single-component water-based acrylic primer suitable for water-based lacquering of wooden floors. ECOSTARTER has excellent chemical and physical properties has: transparency, easy sandability and adequate solid content.

Characteristics

Mixture ratio	single-component
Application temperature	+10°C ÷ +25°C
Application	8 mm microfiber roller / brush / spray
Thinning (if necessary)	DILUENTE DR H2O
Coverage	70-100 g/m ²
Dust dry	20' ⁽¹⁾
Fingerprint dry	30' ⁽¹⁾
Sanding	12 h ⁽¹⁾
Overcoating without sanding	1-3 h ⁽¹⁾
Wood oxidation	low
Pore filling	good
Storage stability	1 year ⁽²⁾
Packaging	5 L - 25 L
Tool cleaning	DILUENTE DNH 40 (with fresh product)

1 at 20°C and 65% R.H.

2 in original sealed containers at temperatures between +10°C and +25°C

How to use

Shake well before use. ECOSTARTER should be applied on wooden floors which have been filled, sanded (120/150 paper grit) and thoroughly vacuumed. It is possible after 2 hours from the first application (without sanding) or after 12/24 hours (prior sanding with 280/320 paper grit) to apply another coat of ECOSTARTER. The subsequent lacquering, previous proper sanding, has to be done with ECOSTAR, ECOSTAR 2K, ECOWOOD 2K or ECOTRAFFIK 2K (see technical data sheets).

Notes: if lacquering tannin wood species, it is suggested to run a preliminary test.

Label elements

· Safety data sheet available on request. Contains MIXTURE OF: 5-CHLORO-2-METHYL-2H-ISOTHIAZOL-3-ONE; 2-METHYL-2H-ISOTHIAZOL-3-ONE (3: 1). May produce an allergic reaction.

Web link

Be sure to have the latest version of this technical data sheet downloadable also from the following link:



http://www.chimiver.com/tds/EN_ECOSTARTER.pdf