

PRYMER ELASTOXYL

Primer for wood



Description

PRYMER ELASTOXYL is a primer used to obtain good performance and excellent adhesion on porous surfaces and on greasy wood species (i.e. Teak). PRYMER ELASTOXYL should be used before applying ELASTOXYL PU, Elastic silane sealant for outdoor.

Characteristics

Appearance	liquid
Colour	transparent
Application temperature	+10°C ÷ +35°C
Application	special brush
Reticulation	moisture
Hardening	Greater than 30 min. - Lower than 60 min.
Storage stability	9 months ⁽¹⁾
Packaging	bottle 1 L - bottle 5 L
Coverage	1 l = 20 m ²
Tool cleaning	DILUENTE ACETONE
Hands and skin cleaning	Towels Mani Pulite

1 in original sealed containers at temperature between +10°C and +25°C

How to use

PRYMER ELASTOXYL has to be used on surfaces free of dust, detaching and contaminating materials. The surfaces must be clean and degreased using DILUENTE ACETONE. Pour the primer in another container. Do not pour the remains of the primer back into its original bottle. Spread PRYMER ELASTOXYL with a special brush, paying attention to distribute it uniformly overall. The minimum drying time of the primer is 30 minutes (at +20°C, 50% R.H.), during which the treated surface should not come into contact with dust, detaching agents and should be protected from bad weather impact and direct exposure to UV rays. The best performance of gluing and sealing takes place between 30 min. and 60 min. after application of PRYMER ELASTOXYL. If more than 24 hours are passing, repeat the application of PRYMER ELASTOXYL before using ELASTOXYL PU (see technical data sheet).

Label elements

· Highly flammable liquid and vapour. · Causes serious eye damage. · May cause drowsiness or dizziness.

· Repeated exposure may cause skin dryness or cracking.

· Keep away from heat / sparks / open flames / hot surfaces. No smoking. · Keep container tightly closed. · Wear protective gloves / protective clothing / eye protection / face protection. · IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. · Immediately call a POISON CENTER or doctor / physician.

Contents: PROPAN-2-OL; N-BUTYL ACETATE; ETHYL ACETATE; 3-(TRIMETHOXSILYL)PROPYLAMINE;



Web link

Be sure to have the latest version of this technical data sheet downloadable also from the following link:



http://www.chimiver.com/tds/EN_PRYMER_ELASTOXYL.pdf