

Item Code: PSF1000A | Rev.: 14-07-2021 | Ver: 3.2

PRYMER SF 1105

Two-component water-based epoxy primer for subfloors preparation





¤Description

PRYMER SF 1105 is a two-component water-based epoxy primer developed for dusty subfloor, with a multi-layer application, it works as a moisture barrier. It is resistant to the inverse hydrostatic pressure according to the law UNI 8298 part 8. PRYMER SF 1105 is suitable for consolidation of subfloors on radiant heating. It is also recommend as a promoter of adhesion for anhydrite subfloors.

¤Characteristics	
Mixture ratio	1:1
Application temperature	+10°C ÷ +25°C
Application	8 mm microfiber roller / brush
Thinning (if necessary)	water
Coverage	150-500 g/m² depending on the
	subfloor and use
Total drying time	2 - 6 h
Pot-Life	ca. 1 h ⁽¹⁾
Storage stability	1 year ⁽²⁾
Packaging	20 Kg (10+10) - 10 Kg (5+5)
Tool cleaning	water
1 at 20°C and 65% R.H.	
2 in original sealed container	s at temperatures between +10°C and +25°C

#How to use

Restoration of dusty subfloors

Clean the subfloor to be treated by eliminating totally any trace of oil, grease, wax, or paint spots. The subfloor must be free from cracks. Mix component A and B (ratio 1:1) manually or with electric tools, without creating excessive foam. When necessary, dilute with 10% of water before use. Apply 150 g/m² by roller and lay the parquet after 2 h from the application of PRYMER SF 1105. In case of subfloors with low absorption, dilute with higher quantities of water (up to 20%).

Adhesion promoter for anhydrite subfloors

Sandpaper properly the anhydrite subfloor with large-grains paper till you get a white powder. Vacuum clean the surface well and apply one coat of PRYMER SF 1105 diluted at 10% with water, applying 150 g/m².

Moisture barrier

PRYMER SF 1105 is able to create a moisture barrier on foundations of 6cm in depth and Residual Humidity of 5%, measured with the carbide method.

Clean the subfloor to be treated by eliminating totally any trace of oil, grease, wax, or paint spots. The subfloor must be free from cracks. Mix component A and B (ratio 1:1) manually or with electric tools, without creating excessive foam. Apply 200 g/m2 by roller. After curing (2 hours), apply a 2nd coat (200 g/m²). In case of subfloors with low absorption, PRYMER SF 1105 could create a superficial film. Spread some quartz (diameter 0,6 mm)

on to the wet surface after the 2nd hand. The excess of quartz will be removed with a broom.

We advise to use the following adhesives: UNISIL, ADESIVER ELASTIC, ADESIVER 501 EP, SIGOL, ADESIVER HERCULES, ADESIVER 327 PU (see relative technical data sheets), after application of PRYMER SF 1105.

The total quantity of PRYMER SF 1105 to ensure the correct creation of a moisture barrier is at least of 400 g/m^2 .

In case of powdery subfloors, the first coat as anti-dust has to be considered separately from the total quantity of $400~g/m^2$ for moisture barrier.

ELabel elements

· Causes serious eye irritation.· Causes skin irritation.· May cause an allergic skin reaction.· Toxic to aquatic life with long lasting effects.

· Contains epoxy constituents. May produce an allergic reaction.

 Dispose your waste in dedicated collection points. Keep out of reach of children. Wear protective gloves / protective clothing / eye protection / face protection. If medical advice is needed, have product container or label at hand. Avoid release to the environment.

Contents:REACTION PRODUCT: BISPHENOL A-(EPICHLORHYDRIN); REACTION PRODUCT: BISPHENOL F-EPICHLORHYDRIN; OXIRANE, MONO[(C12-14-ALKYLOXY)METHYL] DERIVS;



omp.B

Causes serious eye irritation.· Causes skin irritation.· May cause an allergic kin reaction

 Dispose your waste in dedicated collection points. Keep out of reach of children. Wear protective gloves/protective clothing/eye protection/face protection. If medical advice is needed, have product container or label at hand. Avoid breathing dust/fume/gas/mist/vapours/spray.
Contents:POLYMER ABDLE ISOLATED:



¤Web link

Be sure to have the latest version of this technical data sheet downloadable also from the following link:



http://www.chimiver.com/tds/EN_PRYMER_SF_1105.pdf

These information are given from the best of our knowledge and technical experience. They are of general character and not binding in any way our company. Every single case should be put to a pratical test by the user who assumes the full responsability of the final result of his work.